

# QUICKFLEX















## SPECIFICATIONS

## **APPLICATION**

- 1. Cut the material in reverse with a Flex blade
- 2. Weed the excess material
- 3. Heat press on a SEFA machine on the garment at 165 ° C & Protect the polyester carrier with silicone paper

5 sec - medium pressure

4. Peel the carrier off when hot

THICKNESS:



Polyurethane 80 microns

**CARRIER:** Adhesive & Transparent polyester

CERTIFICATES: Oeko-Tex Label Standard 100 Class I



### APPLIES ON

Cotton • Polyester • Acrylic & Similar Fibres

#### CARE & MAINTENANCE

- Always respect the garment's instructions
- -> Allow 24 hours after application before washing
- → Iron the backside only

#### **WASH**

- Max 60° C
- Preferably inside out
- Do not bleach
- Tumble-dry approved
- Dry-cleaning unapproved

#### **STORE**

- Up to 1 year
- In a dry room (15-30° C)
- Away from sunlight
- In vertical position

